

# INF250: Mandatory Exercise02

- Author: Mahrin Tasfe
  - Email: mahrin.tasfe@nmbu.no
- 
- 

## Solution starts here

---

### Step01: cropping the extra part of the image

Select necessary part of the image → Goto Image in imageJ → Select crop



Figure-01: Cropped image

### Step02: Converting the image to a 8-bit image

Goto Image in imageJ → Type → 8-bit




Figure-02: 8-bit image

### Step03: Trying out all binarising methods

Goto image → Adjust → Auto Threshold → try all




Figure-03: Trying all thresholding methods

#### Step04: Choosing the best threshold method for binarising the image:

From the figure-4, we can see that **Triangle** does the best job at binarising with minimum holes. For this reason, I have chosen triangle threshold method.

Goto image → Adjust → Auto Threshold → Triangle




Figure-04: Binarising with Triangle thresholding

#### Step05: Inverting the binary image

Because usually we want the objects to be white and the background to be black.

Goto Edit → Invert




Figure-05: Inverted Binary image

## Step06: Filling the holes after binarisation of image

Goto Process → Binary → Fill holes




Figure-06: Filling the holes after binarisation

## Step07: For analyzing setting the objects descriptors

Goto Analyze → Set Measurements → Select the Area, Center of mass, Shape descriptors, Display label → Change the decimal places from 2 to 5. Since it is a binary image the max value will always be 255 and minimum value will be 0.




Figure-07: Set measurements

## Step08: Identifying all objects present in the image

Goto Analyze → Analyze Particles → Ok (without making any changes)




Figure-08: Analyze particles with default setting




Figure-09: Object identification & analyze (1)

Label	Area	XM	YM	Circ.	AR	Round	Solidity
871	ans_filledt.tif	5	81.50000	2946.30000	0.38785	2.32359	0.43037 0.47619
872	ans_filledt.tif	1	122.50000	2945.50000	1.00000	1.00000	1.00000
873	ans_filledt.tif	4	136.25000	2946.25000	0.85737	2.00000	0.50000 0.80000
874	ans_filledt.tif	1	143.50000	2945.50000	1.00000	1.00000	1.00000
875	ans_filledt.tif	1	147.50000	2945.50000	1.00000	1.00000	1.00000
876	ans_filledt.tif	1	139.50000	2946.50000	1.00000	1.00000	1.00000
877	ans_filledt.tif	7	184.78571	2948.07143	0.80011	1.66783	0.59598 0.77778
878	ans_filledt.tif	1	394.50000	2946.50000	1.00000	1.00000	1.00000
879	ans_filledt.tif	3	12.50000	2948.50000	0.80852	3.00000	0.33333 1.00000
880	ans_filledt.tif	2	52.00000	2947.50000	1.00000	2.00000	0.50000 1.00000
881	ans_filledt.tif	2	108.00000	2948.00000	0.78540	2.64575	0.37796 0.66667
882	ans_filledt.tif	2	114.50000	2946.00000	1.00000	2.00000	0.50000 1.00000
883	ans_filledt.tif	1	141.50000	2947.50000	1.00000	1.00000	1.00000
884	ans_filledt.tif	1	171.50000	2947.50000	1.00000	1.00000	1.00000
885	ans_filledt.tif	16	50.93750	2950.43750	0.43269	2.44854	0.40841 0.61538
886	ans_filledt.tif	1	70.50000	2948.50000	1.00000	1.00000	1.00000
887	ans_filledt.tif	1	168.50000	2948.50000	1.00000	1.00000	1.00000
888	ans_filledt.tif	2	105.00000	2950.00000	0.78540	2.64575	0.37796 0.66667
889	ans_filledt.tif	4	139.00000	2950.00000	1.00000	1.00000	1.00000
890	ans_filledt.tif	1	152.50000	2949.50000	1.00000	1.00000	1.00000
891	ans_filledt.tif	1	157.50000	2949.50000	1.00000	1.00000	1.00000
892	ans_filledt.tif	2	193.50000	2950.00000	1.00000	2.00000	0.50000 1.00000
893	ans_filledt.tif	1	42.50000	2950.50000	1.00000	1.00000	1.00000
894	ans_filledt.tif	4	63.50000	2951.25000	1.00000	1.46760	0.68139 0.80000
895	ans_filledt.tif	1	68.50000	2950.50000	1.00000	1.00000	1.00000
896	ans_filledt.tif	3	79.16667	2950.83333	1.00000	1.46385	0.68313 0.85714
897	ans_filledt.tif	2	141.50000	2951.00000	1.00000	2.00000	0.50000 1.00000
898	ans_filledt.tif	1	172.50000	2950.50000	1.00000	1.00000	1.00000
899	ans_filledt.tif	1	18.50000	2951.50000	1.00000	1.00000	1.00000
900	ans_filledt.tif	3	23.50000	2951.50000	0.96737	3.00000	0.33333 1.00000
901	ans_filledt.tif	1	145.50000	2951.50000	1.00000	1.00000	1.00000

Figure-10: Object identification & analyze (2)

From figure-09 and figure-10, we can see that 901 objects have been identified. But visibly, we can see that we do not have that many objects present in the image. So for ignoring the noises present in the image, we need to change the starting size of the particles from 0 to 1000.

## Step09: Identifying all objects present in the image ignoring the noises

Goto Analyze → Analyze particles → Change starting value of the size from 0 to 1000 → Ok




Figure-11: Analyze particles with custom size setting

Label	Area	XM	YM	Circ.	AR	Round	Solidity	
14	ans_filled.tif	64048	1142.93277	842.93289	0.89088	1.05470	0.94814	0.99238
15	ans_filled.tif	66654	1532.86826	857.70926	0.89426	1.03933	0.96216	0.99249
16	ans_filled.tif	70797	4005.62153	906.38960	0.88571	1.09934	0.90963	0.99203
17	ans_filled.tif	38316	2088.11721	1060.12371	0.70009	1.83890	0.54380	0.96922
18	ans_filled.tif	67203	344.94574	1131.53460	0.85475	1.34649	0.74267	0.99070
19	ans_filled.tif	66033	1581.16542	1161.36350	0.88423	1.05566	0.94729	0.99275
20	ans_filled.tif	64049	3636.97784	1182.34107	0.89420	1.06600	0.93803	0.99238
21	ans_filled.tif	134681	1365.25503	1369.27211	0.43802	2.30598	0.43368	0.84926
22	ans_filled.tif	461974	2259.45023	1886.38531	0.18106	2.88080	0.34713	0.58069
23	ans_filled.tif	64702	3092.50652	1335.45932	0.69200	1.07649	0.52985	0.99263
24	ans_filled.tif	62933	2032.42711	1414.68500	0.89509	1.03409	0.96704	0.99285
25	ans_filled.tif	68909	3819.82379	1559.40798	0.89116	1.03760	0.96376	0.99286
26	ans_filled.tif	56140	4184.44102	1557.75622	0.77494	1.28738	0.77677	0.95100
27	ans_filled.tif	64273	3465.73406	1611.32202	0.89238	1.05360	0.94913	0.99256
28	ans_filled.tif	66998	1716.94605	1761.12880	0.90144	1.03046	0.97044	0.99309
29	ans_filled.tif	450198	2998.00987	2154.77978	0.19164	1.74623	0.57266	0.64519
30	ans_filled.tif	59513	1330.04891	1891.65718	0.78087	1.25085	0.79946	0.96237
31	ans_filled.tif	64346	2435.07923	1946.82044	0.89412	1.06803	0.93630	0.99297
32	ans_filled.tif	63076	1746.71785	2051.83079	0.89113	1.04845	0.95379	0.99205
33	ans_filled.tif	67820	3878.61673	2116.60986	0.90280	1.02558	0.97505	0.99281
34	ans_filled.tif	68020	1098.94266	2292.26868	0.89553	1.05344	0.94927	0.99254
35	ans_filled.tif	71233	4157.09731	2366.31068	0.88969	1.06370	0.94011	0.99221
36	ans_filled.tif	133940	1694.89077	2425.90572	0.50780	2.14178	0.46690	0.88160
37	ans_filled.tif	74640	732.39148	2414.87252	0.88531	1.04173	0.95994	0.99205
38	ans_filled.tif	67963	3591.50705	2466.20112	0.89515	1.03024	0.97065	0.99267
39	ans_filled.tif	72535	388.27831	2567.25781	0.85742	1.09517	0.91310	0.98977
40	ans_filled.tif	66210	3318.48316	2630.35990	0.89633	1.02300	0.97748	0.99274
41	ans_filled.tif	67822	953.04782	2685.87907	0.89622	1.07423	0.93090	0.99291
42	ans_filled.tif	66160	3892.66076	2729.38094	0.89674	1.01878	0.98157	0.99172
43	ans_filled.tif	65409	1762.63709	2773.32519	0.89707	1.06296	0.94077	0.99268
44	ans_filled.tif	1206	15.61940	2922.60365	0.03236	1.82662	0.54746	0.51134

Figure-12: Object identification & analyze (1)




Figure-13: Object identification & analyze (2)

From figure-12 and figure-13, we can see that **44 objects** have been identified. But visibly, we can see that few of the objects have been merged with each other. Hence they are considered as a single object. For solving this problem, I have used **Watershed**.

## Step10: Separating the merged objects with Watershed

Goto Process → Binary → Watershed




Figure-14:Separating the merged objects with Watershed

## Step11: Analyzing the Watershed separated objects

Goto Analyze → Analyze particles → Change starting value of the size from 0 to 1000 → Ok  
Save the result file as a CSV.




Figure-15:Analyze particles with custom size setting

Label	Area	XM	YM	Circ.	AR	Round	Solidity	
38	ans_fillet.tif	66281	2277.04894	1668.56643	0.87267	1.10002	0.90907	0.96894
39	ans_fillet.tif	68554	686.61764	1698.71027	0.88672	1.08911	0.92268	0.98509
40	ans_fillet.tif	68898	1716.94605	1761.12888	0.90144	1.03046	0.97044	0.99309
41	ans_fillet.tif	63065	2014.15307	1781.50273	0.88729	1.05007	0.95322	0.98902
42	ans_fillet.tif	64862	2845.67210	1628.18403	0.88255	1.04367	0.95816	0.98900
43	ans_fillet.tif	59513	1330.04891	1891.65718	0.79087	1.25081	0.79946	0.96237
44	ans_fillet.tif	64346	2435.07923	1946.82044	0.89412	1.06803	0.93630	0.99297
45	ans_fillet.tif	66793	3521.52946	1944.72255	0.88229	1.00993	0.99017	0.98872
46	ans_fillet.tif	69869	727.58562	1985.82053	0.88798	1.11436	0.89737	0.98900
47	ans_fillet.tif	64608	2141.61947	2026.61348	0.89589	1.05425	0.94854	0.98849
48	ans_fillet.tif	63811	3264.68589	2047.48665	0.89034	1.02369	0.97686	0.98916
49	ans_fillet.tif	58076	1746.71785	2051.83079	0.89113	1.04845	0.95379	0.99205
50	ans_fillet.tif	43208	448.27090	2045.88470	0.68794	1.66461	0.60072	0.95201
51	ans_fillet.tif	63056	2771.65061	2091.94077	0.88451	1.06209	0.94154	0.98483
52	ans_fillet.tif	67820	3878.61873	2118.60988	0.90280	1.02559	0.97505	0.99281
53	ans_fillet.tif	68020	1098.84266	2250.28866	0.89553	1.05344	0.94927	0.99254
54	ans_fillet.tif	62726	3075.74282	2246.43245	0.89422	1.04630	0.95571	0.98967
55	ans_fillet.tif	68606	2157.21842	2301.20057	0.90156	1.06136	0.94217	0.98891
56	ans_fillet.tif	63786	2826.19457	2359.29603	0.87974	1.03838	0.96307	0.98383
57	ans_fillet.tif	71233	4157.09731	2366.31065	0.88969	1.06376	0.94011	0.99221
58	ans_fillet.tif	65478	1838.71678	2409.38723	0.89718	1.07872	0.92702	0.99251
59	ans_fillet.tif	74640	732.39148	2414.87256	0.88531	1.04173	0.59594	0.99205
60	ans_fillet.tif	68407	1557.21801	2441.72802	0.89072	1.08119	0.92491	0.99276
61	ans_fillet.tif	67963	3591.50705	2466.20112	0.89515	1.03024	0.97065	0.99267
62	ans_fillet.tif	72535	388.27831	2567.25781	0.85742	1.09517	0.91310	0.96977
63	ans_fillet.tif	69538	2241.17517	2577.10558	0.89369	1.02864	0.97216	0.99113
64	ans_fillet.tif	64091	2659.80557	2581.04356	0.89049	1.04871	0.95355	0.99125
65	ans_fillet.tif	66210	3318.48316	2630.35995	0.89633	1.02304	0.97748	0.99274
66	ans_fillet.tif	67822	953.04782	2685.87907	0.89622	1.07423	0.93090	0.99291
67	ans_fillet.tif	66160	3892.66067	2729.38094	0.89674	1.01878	0.98157	0.99172
68	ans_fillet.tif	65409	1762.63709	2773.32519	0.89707	1.06296	0.94077	0.99268

Figure-16: Object identification & analyze (2)




Figure-17: Object identification & analyze (3)

From figure-16 and figure-17, we can see that 68 objects have been identified which are either M&M or Nonstop.

## Step12: Establishing the logic behind distinguishing Non Stops from M&Ms (Approach-01)

From the website of ImageJ we know,

$$\text{Circ. (circularity)} = (4\pi \cdot \text{area}) / \text{perimeter}^2$$

A value of 1.0 indicates a perfect circle. As the value approaches 0.0, it indicates an increasingly elongated shape. Values may not be valid for very small particles.

Sources:

- <https://imagej.nih.gov/ij/docs/menus/analyze.html#set>
- <https://imagej.nih.gov/ij/docs/guide/146-30.html#toc-Subsection-30.7>

In general, we know the **Non-Stops** are **circular** and **M&M's** have a more of an **elongated shape**.

So, if the circularity is approximately 1 or over 0.855 then that the object is almost circular. So, according to this, those are Non-stops. Otherwise, those are M&Ms.

### Condition for distinguishing Non-Stops from M&Ms:

```
If circularity >= 0.855:
    It is Non-stop
Else:
    It is M&M
```

## Step13: Identifying Non-Stops

- Goto Analyze → Analyze particles → set Size (1000-Infinity) → set Circularity (0.855 - 1.0) → Ok




Figure-18:Analyze particles with custom Size & Circularity settings




Figure-19: Non-stops identification

Label	Area	XM	YM	Circ.	AR	Round	Solidity
1 after_watershed.tif	60970	2708.55606	173.26311	0.89578	1.03789	0.96349	0.99300
2 after_watershed.tif	61671	2227.62448	206.40089	0.89106	1.14275	0.87508	0.99267
3 after_watershed.tif	61426	1904.22880	250.07599	0.89277	1.03102	0.96991	0.99241
4 after_watershed.tif	63907	3557.76053	281.77218	0.88519	1.08139	0.92473	0.99194
5 after_watershed.tif	64695	3112.73660	336.20922	0.88803	1.05367	0.94906	0.99201
6 after_watershed.tif	65967	1953.25892	356.40424	0.89016	1.05223	0.95036	0.99187
7 after_watershed.tif	62049	1607.67644	352.89105	0.89027	1.04406	0.95780	0.99110
8 after_watershed.tif	64189	946.02430	523.59982	0.90040	1.03779	0.96358	0.99278
9 after_watershed.tif	73266	194.00756	744.26669	0.87454	1.03149	0.96947	0.99225
10 after_watershed.tif	64640	1858.65656	738.22577	0.88787	1.07038	0.93425	0.99258
11 after_watershed.tif	68945	641.52405	776.52679	0.89119	1.07012	0.93447	0.99125
12 after_watershed.tif	64048	1142.93277	842.93286	0.89068	1.05470	0.94814	0.99236
13 after_watershed.tif	66654	1532.86826	857.70928	0.89426	1.03933	0.96216	0.99249
14 after_watershed.tif	62685	2437.74041	905.89167	0.86871	1.05716	0.94599	0.98495
15 after_watershed.tif	70797	4095.62153	906.38966	0.88571	1.09934	0.90963	0.99203
16 after_watershed.tif	65493	2715.02613	926.15347	0.89070	1.04626	0.95579	0.99221
17 after_watershed.tif	64952	811.54865	992.70925	0.89921	1.04531	0.95665	0.99143
18 after_watershed.tif	63418	3332.22147	1026.28519	0.90078	1.05934	0.94488	0.99256
19 after_watershed.tif	66003	1581.16542	1161.36354	0.88423	1.05564	0.94729	0.99275
20 after_watershed.tif	64049	3636.97784	1182.34107	0.89420	1.06606	0.93803	0.99238
21 after_watershed.tif	69222	1293.99387	1241.46261	0.88623	1.06997	0.93460	0.99304
22 after_watershed.tif	66446	2452.26193	1266.74049	0.87591	1.10990	0.90098	0.98716
23 after_watershed.tif	68910	786.11612	1286.98270	0.89312	1.07235	0.93253	0.99163
24 after_watershed.tif	64702	3092.50652	1356.45932	0.89208	1.07649	0.92894	0.99263
25 after_watershed.tif	62933	2032.42711	1414.68505	0.89505	1.03409	0.96704	0.99285
26 after_watershed.tif	64886	553.93974	1454.69676	0.87565	1.04115	0.96047	0.98854
27 after_watershed.tif	64574	2525.89398	1537.26844	0.88046	1.03908	0.96239	0.98899
28 after_watershed.tif	68909	3819.82379	1559.40795	0.89116	1.03760	0.96376	0.99286
29 after_watershed.tif	68858	960.95140	1613.84484	0.89022	1.03856	0.96287	0.99039
30 after_watershed.tif	64273	3465.73406	1611.32202	0.89238	1.05360	0.94913	0.99256

Figure-20: Non-stops identification & analyze results(1)

Label	Area	XM	YM	Circ.	AR	Round	Solidity
31 after_watershed.tif	66281	2277.04894	1668.56643	0.87267	1.10002	0.90907	0.98894
32 after_watershed.tif	68554	686.61764	1698.71027	0.88672	1.08391	0.92258	0.98509
33 after_watershed.tif	66698	1716.94605	1761.12688	0.90144	1.03046	0.97044	0.99309
34 after_watershed.tif	63065	2014.15307	1781.50273	0.88729	1.05007	0.95232	0.98902
35 after_watershed.tif	64862	2845.67210	1828.18408	0.88255	1.04367	0.98816	0.98900
36 after_watershed.tif	64346	2435.07923	1946.82044	0.89412	1.06803	0.93630	0.99297
37 after_watershed.tif	66793	3521.52346	1944.72255	0.88229	1.00993	0.99017	0.98872
38 after_watershed.tif	69969	727.58552	1985.82053	0.88798	1.11436	0.89737	0.98900
39 after_watershed.tif	64608	2141.61947	2026.81348	0.89599	1.05425	0.94854	0.98649
40 after_watershed.tif	63811	3264.68589	2047.46665	0.89030	1.02369	0.97686	0.98816
41 after_watershed.tif	63076	1746.71785	2051.83979	0.89113	1.04845	0.95379	0.99205
42 after_watershed.tif	63056	2771.65061	2091.94077	0.88451	1.06209	0.94154	0.98483
43 after_watershed.tif	67820	3878.61873	2118.60986	0.90280	1.02558	0.97505	0.99281
44 after_watershed.tif	68020	1098.94266	2250.28688	0.89553	1.05344	0.94927	0.99254
45 after_watershed.tif	62726	3075.74282	2346.43245	0.89422	1.04635	0.95571	0.98867
46 after_watershed.tif	66806	2157.21842	2301.20057	0.90156	1.06138	0.94217	0.98891
47 after_watershed.tif	63786	2826.19457	2359.29602	0.87974	1.03835	0.96307	0.98383
48 after_watershed.tif	71233	4157.09731	2366.31065	0.88969	1.06370	0.94011	0.99221
49 after_watershed.tif	65478	1838.71678	2409.38723	0.89711	1.07872	0.92702	0.99251
50 after_watershed.tif	74640	732.39149	2414.87256	0.88533	1.04173	0.95994	0.99205
51 after_watershed.tif	68407	1557.21801	2441.72802	0.89072	1.08119	0.92491	0.99276
52 after_watershed.tif	67963	3591.50705	2466.20112	0.89515	1.03024	0.97065	0.99267
53 after_watershed.tif	72535	388.27831	2567.25781	0.85742	1.09517	0.91310	0.98977
54 after_watershed.tif	69538	2241.17517	2577.10558	0.89366	1.02864	0.97216	0.99113
55 after_watershed.tif	64091	2659.80557	2561.04356	0.89049	1.04871	0.95355	0.99125
56 after_watershed.tif	62210	3318.48316	2630.35905	0.89633	1.02304	0.97748	0.99274
57 after_watershed.tif	67822	953.04782	2665.87907	0.89622	1.07423	0.93090	0.99291
58 after_watershed.tif	66160	3892.66067	2729.38094	0.89674	1.01878	0.98157	0.99172
59 after_watershed.tif	65409	1762.63709	2773.32519	0.89707	1.06296	0.94077	0.99266

Figure-21: Non-stops identification & analyze results(2)

From figure-19, figure-20 and figure-21, we can see that 59 Non-stops have been identified that have a circularity within the range of (0.855 to 1.0).

## Step14: Identifying M&Ms

- Goto Analyze → Analyze particles → set Size (1000-Infinity) → set Circularity (0-0.855) → Ok




Figure-22: Analyze particles with custom Size & Circularity settings




Figure-23: M&Ms identification

Label	Area	XM	YM	Circ		AR	Round	Solidity
				Circ	AR			
1	18_non_stop.tif	35341	1473.41701	564.92571	0.64952	1.99074	0.50233	0.93662
2	18_non_stop.tif	68109	2544.22886	671.16350	0.85463	1.27308	0.78549	0.98524
3	18_non_stop.tif	66736	3208.26331	740.44170	0.84640	1.39686	0.71589	0.99116
4	18_non_stop.tif	38316	2088.11721	1060.12371	0.70009	1.83890	0.54380	0.96922
5	18_non_stop.tif	67203	344.94574	1131.53460	0.85475	1.34649	0.74267	0.99070
6	18_non_stop.tif	65447	1440.62795	1504.77088	0.83765	1.06413	0.93974	0.98447
7	18_non_stop.tif	56140	4184.44102	1537.75622	0.77494	1.28738	0.77677	0.95100
8	18_non_stop.tif	59513	1330.04891	1891.65718	0.79087	1.25085	0.79946	0.96237
9	18_non_stop.tif	43208	448.27090	2045.88470	0.68794	1.66468	0.60072	0.95201

Figure-24: M&Ms identification & analyze results

From figure-23 and figure-24, we can see that 9 M&Ms have been identified that have a circularity within the range of (0 to 0.855)

The total number of identified M&Ms & Non-stops sums up to the total number of objects identified in the image.

$$= 9(\text{M&Ms}) + 59(\text{Non-stops}) = 68(\text{Total object})$$

#### Problem associated with the solution of Step-14 (Approach-01):

From the figure-23, we can see that few of the M&M detected chocolates are not M&Ms. Rather they are half-eaten Non-stops. So, the area/half-eaten characteristic has to be considered while determining the chocolates.

### Step15: Establishing the logic behind distinguishing Non Stops from M&Ms (Approach-02)

If a chocolate has been eaten its area will be less than a full-sized M&M and Non-stop. From the data, I have identified the area of the smallest full non-stop is 60970 and area of the smallest full M&M is 66448.

So, for determining half-eaten chocolates, I have considered the threshold value of 60000. Any chocolate which has an area less than 60000 is considered half-eaten.

Non-Stops have circularity which is close to 1.0. Since it is half eaten, it will have a circularity greater than or equal to 0.5. Any half eaten chocolate with a circularity less than 0.5 will be considered as M&M.

## Updated conditions for distinguishing Non-Stops from M&Ms:

```
If area >= 60000: #full chocolate
    If circularity >= 0.855:
        It is Non-stop
    Else:
        It is M&M
Else: #Half-eaten chocolate
    If circularity >= 0.5:
        It is Non-stop
    Else:
        It is M&M
```

## Step16: Identifying half-eaten Non-Stops

- Goto Analyze → Analyze particles → set Size (1000-59999) → set size Circularity (0.5-1.0)  
→ Ok




Figure-25:Analyze particles with custom Size & Circularity settings




Figure-26: half-eaten Non-Stops identification

Label	Area	XM	YM	Circ.	AR	Round	Solidity
1	35341	1473.41701	664.92571	0.64952	1.99074	0.50233	0.93662
2	38316	2088.11721	1060.12371	0.70009	1.83890	0.54380	0.96922
3	56140	4184.44102	1557.75622	0.77494	1.28738	0.77677	0.95100
4	59513	1330.04691	1891.65718	0.79087	1.25085	0.79946	0.96237
5	43208	448.27090	2045.88470	0.68794	1.66468	0.60072	0.95201

Figure-27: half-eaten Non-Stops identification & analyze results

From figure-26 and figure-27, we can see that **5 half-eaten Non-Stops** have been identified.

## Step17: Identifying half-eaten M&Ms

- Goto Analyze → Analyze particles → set Size (1000-59999) → set size Circularity (0-0.5)  
→ Ok




Figure-28:Analyze particles with custom Size & Circularity settings




Figure-29: half-eaten M&Ms identification

From figure-28 and figure-29, we can see that **No half-eaten M&Ms** has been identified.

## Step18: Identifying full-size Non-Stops

- Goto Analyze → Analyze particles → set Size (1000-59999) → set size Circularity (0.5-1.0)  
→ Ok




Figure-30:Analyze particles with custom Size & Circularity settings




Figure-31: full-size Non-Stops identification

Label	Area	XM	YM	Circ.	AR	Round	Solidity	
31	after_watershed.tif	66281	2277.04934	1668.56643	0.87267	1.10002	0.90907	0.98894
32	after_watershed.tif	68554	686.61764	1698.71027	0.88672	1.08391	0.92258	0.98609
33	after_watershed.tif	66898	1716.94605	1761.12688	0.90144	1.03046	0.97044	0.99309
34	after_watershed.tif	63065	2014.15307	1781.50273	0.88729	1.05007	0.95232	0.98902
35	after_watershed.tif	64862	2845.67210	1829.18408	0.88255	1.04367	0.96116	0.98900
36	after_watershed.tif	64346	2435.07923	1946.82044	0.89412	1.06803	0.93630	0.99297
37	after_watershed.tif	66793	3521.52346	1944.72255	0.88229	1.00993	0.99017	0.98872
38	after_watershed.tif	69969	727.58552	1985.82053	0.88798	1.11436	0.89737	0.98900
39	after_watershed.tif	66898	1716.94605	1761.12688	0.89589	1.05425	0.94854	0.98849
40	after_watershed.tif	63811	3264.68589	2047.48665	0.89034	1.02369	0.97686	0.98916
41	after_watershed.tif	63076	1746.71785	2051.83079	0.89113	1.04845	0.95379	0.99205
42	after_watershed.tif	63056	2771.65061	2091.94077	0.88451	1.06209	0.94154	0.98483
43	after_watershed.tif	67820	3878.61873	2118.60986	0.90289	1.02558	0.97055	0.99281
44	after_watershed.tif	68020	1098.94266	2250.28668	0.89553	1.05344	0.94927	0.99254
45	after_watershed.tif	62726	3075.74282	2246.43245	0.89422	1.04635	0.95571	0.98967
46	after_watershed.tif	66908	2157.21842	2301.20057	0.90159	1.06138	0.94217	0.98891
47	after_watershed.tif	63786	2826.19457	2359.29602	0.87974	1.03835	0.96307	0.98383
48	after_watershed.tif	71233	4157.09731	2366.31065	0.88969	1.06370	0.94011	0.99221
49	after_watershed.tif	65478	1838.71678	2409.38723	0.89718	1.07872	0.92702	0.99251
50	after_watershed.tif	74640	732.39148	2414.67256	0.88551	1.04173	0.95994	0.99205
51	after_watershed.tif	68407	1557.21801	2441.72802	0.89072	1.08119	0.92491	0.99276
52	after_watershed.tif	67963	3591.50705	2461.20112	0.89516	1.03024	0.97065	0.99267
53	after_watershed.tif	72535	388.27831	2567.25781	0.85742	1.09517	0.91310	0.98977
54	after_watershed.tif	69538	2245.17517	2577.10558	0.89366	1.02864	0.97216	0.99113
55	after_watershed.tif	64091	2659.80557	2581.04356	0.89049	1.04871	0.95355	0.99125
56	after_watershed.tif	66210	3318.48316	2630.85905	0.89633	1.02304	0.97748	0.99274
57	after_watershed.tif	67822	950.04782	2685.87907	0.89622	1.07423	0.93090	0.99291
58	after_watershed.tif	66160	3892.66067	2729.38094	0.89674	1.01878	0.98157	0.99172
59	after_watershed.tif	65409	1762.63709	2773.32519	0.89707	1.06296	0.94077	0.99268

Figure-32: full-size Non-Stops identification & analyze results

From figure-31 and figur-32, we can see that **59 full-size Non-Stops** have been identified.

## Step19: Identifying full-size M&Ms

- Goto Analyze → Analyze particles → set Size (1000-59999) → set size Circularity (0-0.5)  
→ Ok




Figure-33: Analyze particles with custom Size & Circularity settings




Figure-34: full-size M&Ms identification

Label	Area	XM	YM	Circ.	AR	Round	Solidity	
1	after_watershed.tif	68109	2554.22886	671.16350	0.85463	1.27308	0.78549	0.98524
2	after_watershed.tif	66736	3208.26331	740.44170	0.84640	1.39868	0.71589	0.99116
3	after_watershed.tif	67203	344.94574	1131.53460	0.85475	1.34649	0.74267	0.99070
4	after_watershed.tif	65447	1440.62795	1504.70888	0.83765	1.06413	0.93974	0.98447

Figure-35: full-size M&Ms identification & analyze results

From figure-28 and figur-29, we can see that **4 full-size M&Ms** has been identified.

The total number of identified M&Ms & Non-stops sums up to the total number of object identified in the image.

$$= 4(\text{full-size M&Ms}) + 59(\text{full-size Non-stops}) + 0(\text{half-eaten M&Ms}) + 5(\text{half-eaten Non-stops}) = 68(\text{Total object})$$

**Using the approach-02, I was able to sucessfully identify Non-stops and M&M despite few of the chocolates being half eaten.**

In [ ]:

